Thomas@Betts

INSTALLATION INSTRUCTIONS Snap-N-Seal®

F Male Connector Series, One-Piece
Cat. Nos. SNS1P11, 716SNS1P11, SNS1P7, SNS1P7Q and SNS1P8MMAS

Prepare cable using LRC CST596711 tool as follows: (When using Messengered/Siamese cable: Rib must be removed flush with cable jacket before connector installation, this will insure proper installation and sealing.)

 Cut the cable end off square before starting cable preparation. Ensure that the gray cartridge is properly mounted in the front position as shown. Open tool by squeezing the handle, then insert the cable up to the cable stop (see Figure 1).


Rotate tool as shown, 1 to 2 turns, or until tool turns freely. Pull tool from cable to complete the cable preparation. Cable end should appear as shown (see Figure 2).

If using single braid cables, fold the braid over the jacket. If using double braid cables, fold the outer braid over the jacket. Score and remove foil (if applicable). Fold the inner braid over the jacket (see Figure 3).

- 2) To determine how far you should insert the cable: Place cable next to the connector as shown. Position the dielectric at the installation groove (point A). Mark the cable jacket at the edge of the connector, at point B (see Figure 3).
- 3) Insert prepared cable end into the connector through the plastic sleeve. Ensure that the center conductor of the cable and foil covered dielectric are properly aligned with the connector post (see Figure 4).

Insert cable dielectric into the connector post. Push and twist connector until the cable bottoms inside of the connector (mark at point B will be even with the end of the connector) (See Figure 4).

NOTE: If necessary to facilitate cable alignment and insertion, the sleeve can be removed by pressing sideways by hand. If needed, the use of a suitable tool such as a pair of pliers will increase leverage for sleeve removal. Do not over grip the sleeve. Keep the sleeve inserted over the cable, push cable fully into connector and then push sleeve back into connector.



WARRANTY: Thomas & Betts sells this product with the understanding that the user will perform all necessary tests to determine the suitability of this product for the user's intended application. Thomas & Betts warrants that this product will be free from defects in materials and workmanship for a period of ninety (90) days following the date of purchase. Upon prompt notification of any warranted defect, Thomas & Betts will, at its option, repair or replace the defective product or refund the purchase price. Proof of purchase is required. Misuse or unauthorized modification of the product voids all warranties.

Limitations and Exclusions: THE ABOVE WARRANTY IS THE SOLE WARRANTY CONCERNING THIS PRODUCT, AND IS IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE SPECIFICALLY DISCLAIMED. LIABILITY FOR BREACH OF THE ABOVE WARRANTY IS LIMITED TO COST OF REPAIR OR REPLACEMENT OF THE PRODUCT, AND UNDER NO CIRCUMSTANCES WILL THOMAS & BETTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

4) Insert connector (with cable) into LRC installation tool #L3011B. Seat plastic sleeve into the pocket of the tool jaw. Squeeze handles together. The black plastic sleeve and the white pin insulator should both snap into place, with o-ring completely hidden under the collar. The plastic insulator holding the pin, should be below or flush with connector interface (see Figure 5).

Seal the connector to the port using LRC's Thread Protectors (see Figure 6).

Using the TP Cart, determine which thread protector should be used for your length.

TP CHART			
LRC Part #	Port Length		Fig.#
	Min.	Max.	rig.#
TP275	.275	.335	7
TP450	.450	.510	8

Push the larger diameter end, (See Figure 7 or 8), over the F interface until seated against the interface surface, (see Figure 9).

5) Thread SNS connector onto port and wrench tighten 25 to 30 in. lbs. The end of the F connector nut should push against the end of the thread protector to ensure proper sealing.




Figure 5



Figure 6 Thread Protectors




Figure 7

