

RPT MOPTITE® Poke Through Cover

Installation Instructions for

Catalog Numbers: RPT-CVR-SW-TALM & RPT-CVR-SW-TBRS



- 2. PREPARE FLOOR FOR COVER INSTALLATION: TILE, WOOD, CARPET, and LINOLEUM: remove or install floor material leaving a 7" diameter opening around center of poke through. CONCRETE: no preparation required (See Figure 2).
- 3. Install the provided mounting plate to the exposed mounting ring using the four FHMS #8-32 screws provided with cover.
- 4. APPLY SEALANT TO FLOOR: CARPET AND CONCRETE: Apply complete bead of sealant or caulk directly to concrete around mounting plate to within 1/4" from outside edge of plate. On carpet, keep sealant within 7" diameter cut-out. TILE, WOOD and LINOLEUM: Apply moderate amount of sealant directly on finished floor next to cut-out edge. Fully surround 7" diameter opening in
- floor. Use enough sealant to block water entry. 5. Install new RPT MOPTITE® cover using four oval head #6-32 screws
- provided with cover. Clean excess sealant from around cover edge. 6. If cover is installed on concrete floor and no finished floor is planned,
- grout outside bottom edge of cover to fill gap.





Limitations and Exclusions: THE ABOVE WARRANTY IS THE SOLE WARRANTY CONCERNING THIS PRODUCT, AND IS IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE SPECIFICALLY DISCLAIMED. LIABILITY FOR BREACH OF THE ABOVE WARRANTY IS LIMITED TO COST OF REPAIR OR REPLACEMENT OF THE PRODUCT, AND UNDER NO CIRCUMSTANCES WILL THOMAS & BETTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Thomas & Betts Corporation Memphis, Tennessee www.tnb.com